Applechem Formulary - Color Cosmetics



Skin Perfecting Setting Powder CC-LP 001

Talc-free setting powder with a smooth, creamy, weightless finish. It has an anticaking feature that prevents clumps and allows seamless blend into the foundation. Apply just the right amount to prevent that thick, unnatural look under bright lights.

APPLECARE PDS 300 provides even distribution of powders to provide a smooth sensory and better adhesion on the skin, which enables a nude look without cakedon makeup.

APPLECARE PDS 300

- Serves as a **liquid binder** to bind up to 90% powder in the formulation.
- Keeps pigments from re-agglomerating, creating a lighter, smoother texture during application.
- Boosts setting powder functionality, requiring less powder during application to achieve that mattefying effect.
- Provides color correcting effects while creating more "true" color shades for more accurate color matching.

Processing Method

- Mix and grind part A in a grinder.
 Add into part B and blend until homogenous.
- Separate part C into several small portions. Add one small portion into part A/B each time and blend until homogenous.
- 3. Grind the mixture again and sieve into container.

PHASE	INCI NAME (TRADE NAME)	USAGE (WT%)
Α	Titanium Dioxide	2.00
	Yellow Iron Oxide	1.00
	Red Iron Oxide	0.50
	Black Iron Oxide	0.10
В	Mica	70.4
	Poly (Methyl Methacrylate)	10.0
	Corn Starch Modified (Dry Flo AF PURE)	3.00
	Silica (Aerosil(R) 200)	3.00
С	C13-15 Alkane (Hemisqualane)	2.50
	Applecare PDS 300	7.30
	Preservative	0.20

Create Possibilities

EDITION: NOVEMBER 2018 REF #: LP 1809-2 AND LP 1809-C